




## **DIY Art Caddy**

## **Materials List**

- (1) 1x6x22" Pine or Hemlock
- (2) 1x6x5.5" Pine or Hemlock with 45 degree miters on the top corners
- (2) 1x4x22" Pine or Hemlock
- (22) 1 1/2" Finish Nails
- (1) Quart Water Based Stain
- (2) 3" Pulls







2. Set the bottom piece on top of the two 1x4 side pieces, lining them up so the edges are flush.



3. Drive all of the nails in with a hammer.



4. Predrill holes for the pulls near the top of the end pieces and start 6 nails in each.



5. Line up the end pieces with the sides and bottom and drive all of the nails.



6. Your unfinished art caddy will look like this.





7. Stain or paint your art caddy to any color of your liking. We chose a purple water based stain for ours.

8. Install the pulls on each end and your caddy is ready to fill with art supplies!